

DWP 1110 78 Installation Instructions

If your truck originally had these, you should have holes in your door, on the front edge by the hinge and on the rear of the door by the latch. Start at the rear (photo A) and run it across the top and down the front of the door (photo B), it should be tight, you may need to stretch it a little. Confirm it lines up with the area by the hinge (photo B)

Then you need to take weatherstrip adhesive and glue the seal down (photo C), taping it in place until the adhesive dries.

