

C10 Door Panel Early Design

If your door panel is an early design that used longer clips, you will need to trim the panel for the Precision Replacement Parts inner beltline to fit correctly.

1. Remove the old beltline moldings
2. You will need to mark $\frac{1}{4}$ " from the bottom of the lip on the panel, then draw a line across the whole panel



3. Carefully cut the panel along the line. You can use snips, score it with a razor knife and break it off, even a Dremel type tool with a cut off wheel will work. The panel will be brittle so use caution and take your time.



4. Once cut you can install the new beltline, it should line up to the top edge of the panel, if it is below the top edge you did not remove enough material and will need to remove a bit more material

